

ATTACHMENT GUIDE

Vacuworx Portable Vacuum Lifting Systems can be used in conjunction with a variety of host machines. Please refer to the examples below for best practices regarding attachment of the pads to different equipment. You should always confirm that the lift capacities of both the host machine and the attachment device, as well as any rigging equipment used, are adequate for the load you are handling.



PT8300-400A
PS/SL Mounting Assembly for
Mini Skid Steer (top mount)



PT8300-700
Skid Steer Boom with Basket



PT8712-742
PS1 Toro Mounting Bracket
(for eDingo)



PT8600-400
PHD Forklift Adapter




PS1DLY
Lift Dolly



PT8713-000
PHD Below-the-Hook-Basket



PT8713-020
Sherpa Mini Skid Steer
Boom Adapter



PT8712-138
PHD Demolition Robot
Mounting Assembly



PT8712-238
PHD Vertical Lift Skid Steer
Mounting Assembly



PT8715-770
PHD Below-the-Hook-Box

NOTE: This guide does not address every possible attachment option. Safety is our primary concern in any lifting situation. The pad should be securely attached to the host machine with a stable connection point (to minimize swing). All components must have a proper load rating. If you have questions regarding safe lifting practices, please contact Vacuworx.